
About this document

This document provides information about the implementation of the Meridian Integrated Conference Bridge (MICB) in the Meridian 1 system. It describes the MICB operation, installation, configuration, administration, applications, and maintenance.

It focuses on the application and administration of the MICB for scheduling and configuring multiple simultaneous conferences over a single MICB card.

The purpose of this document is to instruct the user how to install, configure, operate, and maintain the Meridian Integrated Conference Bridge (MICB) as a part of the overall Meridian 1 system.

The following describes what you will find in this document:

Product description describes the MICB functional and physical characteristics.

Installation and configuration describes how to prepare the Meridian 1 equipment, how to install the MICB into the Intelligent Peripheral Equipment (IPE) module, how to connect it to the administration terminal, and how to configure the MICB using the system TTY.

Administration describes the MICB administration procedures, MICB parameter configuration, conference scheduling, conference administration and maintenance, and report generation.

Maintenance describes how to perform maintenance functions and how to troubleshoot the MICB card and the associated equipment.

Appendix A lists the MICB pin assignment and connector types for external connections to the MICB.

Appendix B describes reliability, environmental specifications, product integrity, and regulatory standards for the MICB.